
Installation Steps

5-b Wattage setting

DALI




	Article No.: 1009258, 1009259						
ON 	mA	1	2	3	Power (W)		
1 2 3	200	OFF	OFF	OFF	20		
1 2 3	250	ON	OFF	OFF	25		
1.2M	325	OFF	OFF	ON	30		
	375	OFF	ON	ON	35		

ON					
1 2 3 4					
1.5M					


Article No.: 1009260, 1009261							
mA	1	2	3	4	Power (W)		
200	OFF	ON	OFF	OFF	28		
250	ON	ON	OFF	OFF	34		
300	ON	OFF	ON	OFF	41		
350	ON	ON	ON	OFF	48		

6 Connecting Power Supply


3 Wires specification:



5 Wires specification:



7 Assemble the housing



LED Batten P Installation Manual



IMPORTANT SAFETY NOTES



BEFORE YOU BEGIN

- WARNING Read these instructions completely and carefully.
 The installation and connection of the luminaire
 - The installation and connection of the luminaire must be done when switched off and by qualified people. Make sure no voltage while installation.



MAINTENANCE





CAUTION

- To avoid injuries, disconnect power to the light and allow the unit to cool down before performing maintenance.
- Perform visual, mechanical and electrical inspections on a regular basis. We recommend routine checks to be made on an annual basis. Frequency of use and environment should determine this
- The Covers should be cleaned periodically as needed to ensure continued photometric
 performance. Clean the Cover with a damp, non-abrasive, lintfree cloth. If not sufficient, use
 mild soap or a liquid cleaner. Do not use an abrasive, strong alkaline or acid cleaner as damage
 may occur.
- Inspect the topside on the luminaire to ensure that it is free of any obstructions or contamination (i.e. excessive dust build-up). Clean with a non-abrasive cloth if needed.





This product contains a light source of energy efficiency class D.






DWG-P0000 (A)







23.04.2025 SLV GmbH, Daimlerstrasse 21-23, 52531 Übach-Palenberg, Germany Made in China